





## HOW TO INSTALL A DOUBLE CORD TIDY





### What You'll Need:

-  Cord Tidy
-  One screw
-  Drill
-  Pencil

### Important info

Cord tidies are a fast and easy solution for keeping kids and animals from the risk of strangulation. Our blinds come with a compliant child-safety device (cord tidy), which must be installed.

- 1 The cord tidy is a three piece device with a back plate, a centre piece and a front plate. The space between back and centre pieces will hold the chain and the area between the centre and front plate will hold the cord.
- 2 Assemble the cord tidy and position it to the wall at the furthest distance below the vertical system adding appropriate tension to the cord and chain and mark its location. Fig 1
- 3 Split the cord tidy and mark the remaining offset hole position before drilling and plugging both location holes if necessary. Use both of the holes to fix the back piece of the cord tidy to the wall. Fig 2
- 4 Re-assemble the cord tidy with the cord and chain and fix it in position with a screw through the centre hole. Fig 3
- 5 Push fit a cover cap over the screw hole opening. Fig 4



# Vertical blinds

## INSTALLATION GUIDE




## SUPPLIED BRACKETS


Carefully unwrap the Vertical blind and it's associated brackets.

There are a number bracket options for example face fix, top fix screw fit or spring fit.

**Face Fix screw fit bracket**



**Top Fix spring fit bracket**



## INSTALLING VERTICAL BLINDS

### 1 Fitting the brackets

The brackets should be located to allow for the depth of the louvres on the blind. The brackets should therefore be attached to the ceiling or window frame clear from any obstruction on a line 55mm (2 1/8") for 89mm louvres.

For a blind up to 1 metre wide attach two brackets fitted approximately 40mm (1 1/2") from each end of the blind (fig 1).

Any intermediate brackets should be spaced evenly between these and as a general rule:  
Up to 1m = 2 brackets  
1m to 2m = 3 brackets  
2m to 3m = 4 brackets  
Over 3m = 5 brackets

Mark the hole positions before drilling and plugging if necessary. Use two screws for a face fix bracket and one screw in a top fix bracket ensuring that the brackets are level. Remember to allow room for the blind to clear any obstacles when deployed, eg. door or window handles.

### 2 Fitting the Track

The track should be fitted into the brackets keeping the operating cords on the side of the blind as ordered (LH/RH control).

If using a face fix screw bracket, locate the blind with the groove on the back of the headrail and fit it into the middle lip of the bracket. Now push the blind upwards until the headrail is sitting level on the bracket before tightening the securing screw from the front of the blind. Do not over tighten these screws, it is unnecessary and may damage the track.

If using a top fix spring clip bracket you should push the track upwards then tilt away from you to locate the spring bracket front lip into the front groove on the track. Push upwards and the track will click into place.

### 3 Fitting the Louvres

Turn the hooks on the carriers of the track so that the slots are at 90 degrees to the track. Hang the louvres and ensure the seams are all facing the same direction. The blind is now ready to operate.

#### Removing the Track

Before removing a track first take down all the louvres from the blind and release the cord and chain from the cord tidy.

With brackets that have retaining screws, unscrew the retaining screw sufficiently to clear the groove on the blind track. Repeat this with each bracket and the track will come away.

For spring clip brackets push upwards against the tab at the back of the bracket to release the blind from the bracket. Do this with each bracket and the track will come away.

